


VC Quick Installation Guide

1. Installation and Connections


▼ Video Conference - Connecting to PC

Camera System Switch should be set to USB Mode




▼ Video Conference - Connecting to the conference host

Camera System Switch should be set to HDMI Mode



▼ Video Conference - connecting to dual monitor

Camera System Switch should be set to USB Mode



2. Instruction on DIP SWITCH Setting

2.1 System Switch



Setting	Function Descriptions
DIP 1	HDMI / USB Mode OFF : USB Mode(USB and HDMI can output screens simultaneously) ON : HDMI Mode(Only HDMI has output screens)
DIP 2	Output Resolution OFF : 1080P / ON : 720P
DIP 3	Power Frequency OFF : 60Hz / ON : 50Hz
DIP 4	Bulk / ISO Mode OFF : Bulk Mode / ON : ISO Mode

2.2 IR SELECT



ID	Setting
1	<input type="checkbox"/>
2	<input type="checkbox"/>
3	<input type="checkbox"/>