NDI®|HX Setup

If the camera has been activated and enabled at the factory, the following interface should be visible on the WEB page.

NDI configuration interface:

The information displayed on this interface includes the camera name, group name, and NDI version. The user can modify the group name to a private group.



Modify the NDI®|HX camera name:

If you want to modify the NDI®|HX camera name, please enter the information interface, modify the Device ID, and then click the Apply button.



Modify NDI®|HX video resolution:

If you want to modify the resolution of the NDI®|HX stream output, please enter the video interface and modify the resolution configuration parameters. First stream is the main stream of NDI®|HX, and second stream is the auxiliary stream of NDI®|HX.

