


Mode Selection Menu—quickly jump between these five often-used modes using these five buttons.

The *F-Keys* allow you to navigate the pages of a mode or toggle between different functions.

AUDIO TRACKS



Real DAW audio track features let you edit, slice, move and time-stretch your recorded audio performance with total musical control.

SAMPLE EDIT




With the magnifying glass tool selected, use a pinch gesture on the waveform display to zoom in or out. Touch and drag to move the waveform left or right.

STEP SEQUENCER



Touch and drag along the button row to input notes. Use the slider area to tweak their velocities and use the presets bar to load different velocity patterns.

GRID VIEW



Input, erase and select events from the touchscreen interface. Select a range of notes, and use the *F-Keys* to select a modifier operation such as Nudge with all the benefits of true hardware control.

SOFTWARE DOWNLOAD INSTRUCTIONS

Thank you for your purchase! To download your software, follow this link: www.akaipro.com/softwaredownload