VC-B30U Firmware(FW) Upgrade

Please contact Lumens FAE Department through e-mail to get the proper FW and AP before upgrading.

1 Device and Tool Preparation

1.1 Please prepare following devices and tools before FW upgrade.



2 Connections for FW upgrade

**Note: Support: Windows Vista, Windows XP, Windows 7, Windows 8, Windows 10 The VC FW cannot be upgraded through MAC OS.

2.1 Connect the VC camera (RS232 Port) with a PC



2.2 Connect the VC camera (RS232 Port) with a laptop Need 2 cables: RS232 cable and RS232-USB cable



3 FW Upgrade AP

3.1 Please contact Lumens FAE Department through e-mail to get the AP before upgrading.

	Master				Browse
	USB				Browse
	Motor				Browse
	СМ				Browse
	DSP				Browse
I	Ready	ComPort	COM1 -	Pro	ocess

4.1 FW Update

4.1 Launch the [VC-B30U_Download_AP].

				Diowse
USB				Browse
Motor				Browse
СМ				Browse
DSP				Browse
Poady	ComPort	Сом1 -	Pr	ncess
Reauy				00000

4.2 Browse and select proper FW file.

Please check the front box for updating FW. (If there is no need to update specific FW file, please uncheck the box.)

- Master: VHGxxx
- USB: VHHxxx

- Motor: VHSxxx
- CM: VHIXXX
- DSP: VHKxxx



4.3 Select proper [ComPort], and then press [Process] to start.



4.4FW start updating. (Around 8min taken for the five FW update.)

	Master	IG105/VC-B30U_Master_VHG105/VC-B30U_Master_VHG106.bin	Browse		
V	USB	VHG105/VC-B30U_Master_VHG105/VC-B30U_USB_VHH100.bin	Browse		
V	Motor	HG105/VC-B30U_Master_VHG105/VC-B30U_Motor_VHS100.bin	Browse		
V	СМ	J_VHG105/VC-B30U_Master_VHG105/VC-B30U_CM_VHI102.bin	Browse		
	DSP	vHG105/VC-B30U_Master_VHG105/VC-B30U_DSP_VHK100.bin			
	7%	ComPort COM1 - Pro	ocess		

- 4.5 After FW update, please unplug and reconnect the power cord to restart the unit.4.6 Apply the factory reset to the camera
 - 4.6.1 From the menu: [System]-->[Factory Reset]
 - 4.6.2 From the software: [Advance] -->[Factory Reset]



4.2 Check FW version by the [USB PTZ Camera Controller]

4.5.1 Click [Advance] tab and check the FW version on the bottom of the page.

