

# WA12500 DISCRETE MICROPHONE PREAMPLIFIER

## QUICKSTART MANUAL

### **OPERATION**

The **WA12-500** works great with all types of microphones including dynamic, ribbon and condenser microphones. Dynamic microphones and ribbon microphones are generally lower output devices and require no external power source. Condenser microphones are generally more sensitive than dynamic and ribbon microphones and typically require external +48V phantom power.

### **FEATURES**

Your WA12-500 is a completely discrete, high voltage, dual-transformer microphone preamplifier designed for high gain (+71dB), high headroom, low noise and an exciting sonic performance – great for all types of recording applications.

### **HI-Z Input**

The front panel 1/4" input sends the instrument's signal through the entire preamp circuit including the input transformer, discrete opamp (operational amplifier) and output transformer. The thorough layout of the HI-Z's signal path ensures that instruments are subject to the same robust pre-amplification as the microphones. You can connect a variety of instruments via the Hi-Z input on the front panel of the WA12 500 including: acoustic and electric guitars, bass guitar as well as older keyboards with Hi-Z instrument level output.

### HI-Z Switch

This feature engages the front panel 1/4" input and turns off the back panel input on your 500 series rack.

### +48V Switch

The 48 volts feature provides power for condenser mics and any other devices requiring continuous phantom power through the XLR input on your 500 series rack. This power is supplied at a constant level to prevent any degradation of audio quality.

### -20db PAD Switch

Engaging this feature applies -20db to the incoming signal. This is a very useful feature for reducing the level coming into the WA12 500 and thus preventing the signal from clipping or distorting. This may occur due to high output level from a microphone or other device. Padding the input serves to provide increased iheadroomî for the operator while lessening the likelihood of signal overload.

### **POL Switch**

This feature inverts the polarity of the signal. Use the phase invert when recording with more than one open microphone to combat phase cancellation between microphones.

### **TONE Switch**

When engaged the input impedance of the preamp is 150 ohms. When dis-engaged the input impedance of the preamp is 600 ohms. The 150 ohm (switched-in) setting increases the gain of the preamp by +6db changing the maximum gain from +65db to +71db. This feature will make a noticeable tone change to most microphones and instruments. The XLR input on your 500 series rack and the front panel HI-Z input are both altered by this feature.

The 600 ohms impedance setting is recommended for condenser and dynamic microphones, and 150 ohms is recommended for ribbons. This button is labeled "TONE" for a reason though, we strongly suggest you experiment with both settings on all sources to find the best possible tone for your mixes.


### **GAIN Knob**

The gain control is variable and adjusts the gain from +29db to +65db or from +35db to +71db when the iTONEî switch is

engaged. The iPADî feature lowers the minimum and maximum ranges by -20db when engaged.

# POWER Switch

The power button is used to power the unit on and off. To extend the life of the electronics please turn unit off when not in use.





Log on to www.warmaudio.com to register your unit within 14 days of your purchase date to secure your 1 year warranty.

All Content Copyright 2013 Warm Audio - All Rights Reserved